

SECTION D



PLUGS

	<p>Hydraulic symbol</p> <p>Spare part code</p> <p>E70100005</p>	<p>Assembly code</p> <p>G</p> <p>Mounting cavities</p> <table border="1"> <tr><td>0</td><td>1</td></tr> <tr><td>2</td><td>3</td><td>4</td></tr> <tr><td>5</td><td>6</td><td>7</td><td>8</td></tr> </table>	0	1	2	3	4	5	6	7	8
0	1										
2	3	4									
5	6	7	8								
	<p>Hydraulic symbol</p> <p>Spare part code</p> <p>E70100003</p>	<p>Assembly code</p> <p>H</p> <p>Mounting cavities</p> <table border="1"> <tr><td>0</td><td>1</td></tr> <tr><td>2</td><td>3</td><td>4</td></tr> <tr><td>5</td><td>6</td><td>7</td><td>8</td></tr> </table>	0	1	2	3	4	5	6	7	8
0	1										
2	3	4									
5	6	7	8								
	<p>Hydraulic symbol</p> <p>Spare part code</p> <p>E70100006</p>	<p>Assembly code</p> <p>P</p> <p>Mounting cavities</p> <table border="1"> <tr><td>0</td><td>1</td></tr> <tr><td>2</td><td>3</td><td>4</td></tr> <tr><td>5</td><td>6</td><td>7</td><td>8</td></tr> </table>	0	1	2	3	4	5	6	7	8
0	1										
2	3	4									
5	6	7	8								
	<p>Hydraulic symbol</p> <p>Spare part code</p> <p>E70100004</p>	<p>Assembly code</p> <p>L</p> <p>Mounting cavities</p> <table border="1"> <tr><td>0</td><td>1</td></tr> <tr><td>2</td><td>3</td><td>4</td></tr> <tr><td>5</td><td>6</td><td>7</td><td>8</td></tr> </table>	0	1	2	3	4	5	6	7	8
0	1										
2	3	4									
5	6	7	8								
	<p>Hydraulic symbol</p> <p>Spare part code</p> <p>E70100002</p>	<p>Assembly code</p> <p>N</p> <p>Mounting cavities</p> <table border="1"> <tr><td>0</td><td>1</td></tr> <tr><td>2</td><td>3</td><td>4</td></tr> <tr><td>5</td><td>6</td><td>7</td><td>8</td></tr> </table>	0	1	2	3	4	5	6	7	8
0	1										
2	3	4									
5	6	7	8								
	<p>Hydraulic symbol</p> <p>Spare part code</p> <p>E70200010</p>	<p>Assembly code</p> <p>XP</p> <p>Mounting cavities</p> <table border="1"> <tr><td>0</td><td>1</td></tr> <tr><td>2</td><td>3</td><td>4</td></tr> <tr><td>5</td><td>6</td><td>7</td><td>8</td></tr> </table>	0	1	2	3	4	5	6	7	8
0	1										
2	3	4									
5	6	7	8								

Note: cavities 3, 4 and 6 are present on central manifold type UB only.